


Hard Hat Lanyards

Installation and Usage Instructions

HELMET END

Step 1



Choose either an open slot or a secure location on the inner suspension to install the lanyard.

Step 2




Slide the webbing through and around the attachment location and through the cam buckle then cinch tight using the cam buckle.

Step 3



Pull on the lanyard to ensure the connection is secure.

Coil Style



Coil Style lanyards require a cinch around the attachment location.



Do not use Storage Clip as an anchor.

USER END

Step 1



Open the jaws and pinch and fold the clothing. If available always incorporate a seam into the fold. For webbing single ply is acceptable.

Step 2



Insert deeply into the jaws to ensure a good connection.

Step 3




Proper attachment will clamp 4 layers of fabric.

Step 4



Clamp down, and ensure the lanyard is secure.

Anchor Style



For the most secure fit always install the clamp using the anchor loop.

Harness Style



Open the side release buckle and connect the ends around the harness webbing or d-ring.

NOTES

Side Release Buckle



Side release buckles included in some models are for easy removal and reattachment of the lanyard without unclamping either end of the lanyard.

Hard Hat Lanyard Storage Clip (Patent Pending)



Press the clip into an open slot with the words "this side out" on the outside. Ensure it is engaged by pulling. **Do not use as an anchor point.**

Use the storage clip if stowing the lanyard when not in use. Never attach the lanyard clamp directly to a hard hat brim as it will damage the jaws of the clamp.

GENERAL

- Inspect prior to every use.
- Paper style suits affect weight rating (see below).
- Always open jaws to remove, do not pull off without disengaging clamp.
- Caution: Stretched bungee can snap back.
- Do not clamp onto solid objects.
- Only attach to fabrics. Do not clip to fabrics that are thicker than the opening of the jaws.
- Always check and secure both ends of the lanyard following a drop.
- Always test connections. Some fabrics clamp better than others.

Weight Ratings and Pairings

Part Number	Type	Max Weight	Max Wt. for paper, OREX®, or TYVEK® type coveralls
LNHYHRD	Standard	2lb	1lb
LNHYHRDFME	Non- Metal	2lb	1lb
EZLNHYHRDCL	EZ Clean Coil	2lb	1.5lb
EZLNHYHRDAD	EZ Clean Web	2lb	2lb
EZLNHYHRDWBAN	EZ Clean Web	2lb	2lb
LNHYHRDHRN	Harness	2lb	1lb
EZLNHYHRD-MTL	EZ Clean with metal	2lb	1.5lb*

*When incorporating a seam into the clamp.

